

To install your booster cover you just need to follow a few simple steps. Handle with care as the stainless is a mirror finish and will scratch very easily. If you have blue painter's tape you can apply it over the stainless once you remove it from the packaging.

Tools needed:

Grease / wax remover or alcohol

The cover must be installed with both items at room temperature. **If it's cold outside, do the install after a ride or let the engine get up to operating temp with the hood closed.** Keep the cover inside until you're ready to install.

Remove it from the packaging and do a trial fit prior to removing the adhesive film or the white protective covering. It should fit the contour of the booster without having to press it up against it. The back edge can sit under the booster ridge, giving a clean look. You can easily bend the cover to make any final adjustments.

Clean the booster removing any grease or wax (this is critical to a lasting hold) and make sure it 100% dry. Install the VHB disks on the cover on the back side 2 at each at 9, 12 and 3 o'clock

Position the cover over the booster (you may want to remove the vacuum line to give you a little room) slipping the back in first and once you're ready press down into position. Once it touches it's on for good, so make sure prior to allowing it to touch the booster it's where you want it.

Also read the instruction for the care of stainless steel (very important)

Thanks

www.nakidparts.com