

I would suggest installing the bumpers at night or when the car will have a period of inactivity. The adhesive will become it's strongest in 12 -24 hours but it can be used right after installation and is water proof at that time. It's critical that the area is cleaned of all wax and grease. Clean the surface with either isopropyl alcohol or a grease / wax remover (paint prep) sold at auto body supply stores. It should be above 50 deg F for optimal installation. I have provided 3 bumpers so you have a spare. Mark the location, peel back the white paper and press firmly in place. Although it should not be necessary, you can make small changes in the door alignment by shaving off a little of the bumpers tip after 24hrs.

**Install the bumper here on the inside bottom of the door. Placement is critical so you should measure as shown**

**1/8" up from the bottom and 1/8" in from the side inner panel**

