

To install your fuse cover you just need to follow a few simple steps.

If you want it to STICK READ THESE DIRECTIONS

Tools needed:

Grease / wax remover or isopropyl alcohol

The cover must be installed with both items at room temperature. The fuse cover pop right off once in the open position.

For successful application of 3M™ VHB™ Tapes it is important to have clean and dry surfaces, to provide adequate pressure to make contact with the substrates, and to insure application temperature is sufficient to build adhesion. 3M™ VHB™ Tapes will build adhesion with time.

Most substrates are best prepared by cleaning with a 50:50 mixture of isopropyl alcohol (IPA)* and water prior to applying 3M™ VHB™ Tapes.

Do a trial fit so you see how it aligns.

Remove the adhesive film. Position the cover over the fuse box and press firmly (do not apply unless you cleaned as directed above and it's at room temp).

After application, the bond strength will increase as the adhesive flows onto the surface. At room temperature approximately 50% of ultimate bond strength will be achieved after 20 minutes, 90% after 24 hours and 100% after 72 hours.

Thanks

www.nakidparts.com