

Before you start

- **Do not flex this thing cold or over bend it, it will crack . Install room at temp above 60.**
- **Two people, one on each side is much better since you can bend it at the same time.**
- **If you have the halltech make sure you install the radiator side first (vararam the bumper side gets installed first) and then flex it so it fits under the bumper lip.**

The install is so simple but two hands make this much simpler. First, just place the front end of the cover under the nosepiece. **It should be just under the painted bumper but over any bolts and fasteners.**



Then slip the rear under the shroud buy bending the side up in the middle and pushing the edge under the shroud cover. Repeat on the other side if you don't have a helper.



All done